



FRONT

SETTING THE TIME & DATE

Press button A to view the TIME.

Press button B to enter setting mode.

Press A to advance the HOUR in the first column.

Note: PM indicator will light at 12 noon.

Press B to enter MINUTE mode.

Press A to advance the MINUTE in the middle and last column.

Press B to enter Date mode.

Press A to advance the MONTH in the first column.

Press B to enter DAY mode.

Press A to advance the DAY in the middle and last column.

Note: Date will auto-change at midnight.

Press B to set DATE and EXIT the setting mode.

Dual time is situated on the left hand side. Pull out the winder to adjust the time.

READING THE TIME

Press Button A to view the TIME.

Read the first column.

The first 12 lights show the HOUR counted upwards1-2-3-4-5-6-7-8-9-10-11-12.

Example shows 6PM

Next read the middle column to count minutes

(up to 4 mins maximum.) example shows 4 mins.

The right hand column shows tally markings of

5 MINUTES that have passed 05-10-15-20-25...

Example shows 20 mins.

Add the 2 numbers together for the total minutes passed the hour. 4+20

Example shows 24 minutes passed 6th Hour.

READING THE DATE

Press Button A twice to view the DATE.

Read the first column.

The first 12 lights show the MONTH counted upwards Jan-Feb-Mar-Apr-May...Dec.

Example shows August (8th month)

Next read the middle column to count up to 4 days

Example shows 3 days

The right hand column shows tally markings of 5 DAYS that have passed 05-10-15-20-25-30

Example shows 25th Day

Add the 2 numbers together for the Date's Day.

Example shows 28th day of the August (6th month).