

STORM

LONDON

OCEANIC



- L** Light
- M** Mode
- S** Start/Stop
- R** Reset/Split
- C** Analogue Crown

OCEANIC FEATURES

- The Oceanic features quartz analogue time, digital time in hours, minutes and seconds, month, date, day of the week, alarm, hourly chime; stopwatch and lamp illumination.
- Press and hold R to display alarm set time.
- Press and hold S to display month and date.
- Pull out crown and turn anticlockwise to set time.

SETTING TIME AND CALENDAR

- Press M three times to enter time and calendar setting mode.
- Press S to reset seconds to 0.
- Press R to select minutes, hours, date, month and day of week; one unit advances with every push of S.
- Digital time can be specified in AM/PM or 24 hour clock. When advancing hours in time setting mode, AM, PM, or 24 hour time will be indicated by A, P or H in the bottom left of the display. Hours advance in cycles of AM/PM and 24 hour time. When using AM/PM mode, PM will be highlighted on the left hand of the display for PM.
- Press M to return to normal time keeping mode.
- Note that alarm time will be specified as AM/PM or 24 hour as indicated in time setting mode.

LAMP ILLUMINATION

- Press L to activate lamp illumination of the display. The display will automatically switch off after approximately 3 seconds.

HOURLY CHIME

- Hold R and press M to switch hourly chime on/off. Then switched on, press R and days of the week will appear highlighted. When off, press R and days of the week appear unhighlighted.

STOPWATCH MODE

- Press M once to enter stopwatch mode.
- Press S to start stopwatch. Large dot and dial at the top of the display will flash to indicate stopwatch is running.
- Press R for measuring split time, flashing display will remain to indicate stopwatch is still running.
- Press S again to stop stopwatch.
- Press R to reset stopwatch to zero.
- Press M to revert to normal time keeping mode.

SETTING DAILY ALARM

- Press M twice to enter alarm setting mode.
- Press S to set hours. One hour advances with every push of S. AM/PM is indicated by A or P at the bottom left of the display if not in 24 hour time.
- Press R to set minutes. One minute advances with every push of S.
- Press M to return to normal time keeping mode.
- Hold S and press R to turn alarm on. ALM will be highlighted on the right of the dial when the alarm is on. Hold S and press R to turn alarm off. This will also test the alarm sound.
- When alarm sounds, press S to stop, or R to repeat after 3 minutes.