
# STORM

PHERIC



A: Light B: Mode C: Reset D: Date/Start/Stop

## **FEATURES**

- 4 digit LCD display

- Display functions:

Time Calendar Hours, minutes, seconds, 12Hr/24Hr. Day, date, month, year, perpetual calendar.

Alarm Stop watch Daily alarm and hourly chime.

1/100 second chronograph with double

split function.

Light Light up screen while in any mode.

Button tone Tone sounds when button pressed.

# **SETTING SEQUENCE**



## VIEWING THE DAY/DATE

Press 'B' until in Time mode.
Press and hold 'D' to view Day. Month and Date.

#### SETTING THE TIME AND DATE

Press 'B' until in Time mode.

Press and hold 'C' until 2nd beep sounds and digits flash.

Press 'D' to change minute.

Press 'B' to advance to hour digits.

Press 'D' to change hour.

Repeat until entire sequence is correct. See below. Press 'C' to exit back to Time mode.





## SETTING THE ALARM

Press 'B' until in Alarm mode. (ALM)

Press and hold 'C' until 2nd beep sounds and digits flash. Press 'D' to change minute.

Press 'B' to advance to hour digits.

Press 'D' to change hour.

Press 'C' to confirm.

Press 'D' to turn alarm and daily chime On/Off.

If a 'BELL' symbol is visible, the Alarm is On.
If all the days of the week are visible, the Hourly Chime is On.

#### **USING THE LIGHT**

Press 'A' once in any mode to light up the screen. Press and hold 'A' to extend the time that the light is on.

NB. Using the light will use up more battery power.

# **USING THE CHRONOGRAPH**

Press 'B' until in Chronograph mode. (SPL)

Press 'D' to Start and Stop timer.
Press 'C' to reset back to zero.

SPLIT TIME

Press 'D' to Start timer.

Press 'C' to freeze screen. Timer continues to run.

Press 'C' to unfreeze the screen. Timer shows time from start.

Freeze and unfreeze screen as required.

Press 'D' to stop timer completely.

Press 'C' to reset.

WHEN RECORDING TWO DIFFERENT FINISH TIMES

Press 'D' to Start timer.

Press 'C' to freeze screen (1st finish). Timer continues to run.

Press 'D' to stop timer (2nd finish).

Screen still shows frozen time (1st finish).

Press 'C' to view final recorded time (2nd finish).

Press 'C' to reset.