


STORM

FAIRWAY



FEATURES

- Analogue and digital watch with golf score counter.

- Display functions:

Analogue - Hours, Minutes, Seconds.


Digital -	Time	Hours, Minutes, Seconds, AM/PM, 12H/24H
	Calendar	Day, Date, Month, Year, Perpetual calendar.
	Alarm	Indication upto 60min is Min, Sec, 1/100 sec.
	Stop watch	Indication over 60min is Hour, Min, Sec. Max. time up to 24 hours split function.
	Golf score counter	Score for up to 36 holes can be calculated. Accumulation of score displayed automatically.

SETTING THE TIME (ANALOGUE)

1. Pull the crown out one step. The second hand will stop.
2. Set for the correct time by turning the crown.
3. Push the crown back to the original position.
The watch will start running again.

USING THE DIGITAL FUNCTION

1. SETTING SEQUENCE



2. SETTING THE TIME/SELECT 12H or 24H DISPLAY

- Press 'B' until in TIME mode.
Press and hold 'C' - seconds will flash.
Press 'A' to advance seconds to zero.
Press 'C' once - minutes will flash.
Press 'A' to advance minutes.
Press 'C' once - hours will flash.
Press 'A' to advance hours.
Press 'C' once - 12H/24H display will flash.
Press 'A' to choose setting.
Press 'C' once - return to time mode.
Note: If seconds are more than 30 when reset, the time will advance one minute.

3. SETTING THE CALENDAR

Press 'B' until in CALENDAR mode. (one from TIME mode)
Press and hold 'C' - month will flash.
Press 'A' to advance month.
Press 'C' once - date will flash.
Press 'A' to advance date.
Press 'C' once - day will flash.
Press 'A' to advance day.
Press 'C' once - year will flash.
Press 'A' to advance year.
Press 'C' once - return to CALENDAR mode.
Note: When a nonexistent date (e.g., June 31) is set during adjustment, the display will automatically show the first day of the next month after set.
In a leap year, Month end dates will be adjusted automatically.

4. SETTING THE ALARM

Press 'B' until in ALARM mode (two from TIME mode)
Press 'A' to turn alarm ON/OFF.
Press 'C' once - hour will flash.
Press 'A' to advance hours.
Press 'C' once - minutes will flash.
Press 'A' to advance minutes.
Press 'C' once - return to ALARM mode.
Note: If set 'ALARM ON', a symbol will be displayed in all functions, except the GOLF SCORE COUNTER mode.
Press and hold 'A' to hear the alarm sound.

5. STOP WATCH

Press 'B' until in STOP WATCH mode.(three from TIME mode)
Press 'A' to start/stop/restart timer.
Press 'C' when timer is running to measure split time.
Press 'C' when in split mode to view accumulative time.
Press 'C' when in STOP mode to reset counters to zero.

Note: Pressing 'B' at any time when in STOP WATCH mode will advance the display to TIME mode. On returning to STOP WATCH mode, the display will function as previously left. Split time will automatically continue to run.
STOP WATCH display will automatically stop and return to 00'00"00 after running 23 hours 59 minutes 59 seconds 99.
Indication up to 60 minutes is Minute, Second, 1/100 second.
Indication over 60 Minutes is Hour, Minute, Second.

6. GOLF SCORE COUNTER

Press and hold 'B' for 1-2 secs until the beep indicates GOLF SCORE mode.
Press 'C' to advance score.
Press 'A' to subtract score.
Press 'B' to set up for the next hole.
Repeat above actions until the 18th hole is reached.
Press 'B' to set up for the next round of 18 holes.
A second dot will appear in the HOLE NO. display, to indicate second round.
Repeat above actions as before until the second 18th hole has been played.
Press 'B' to view score for each hole played.
Press and hold 'A' and 'C' simultaneously to reset.
Press and hold 'B' to advance to TIME mode.

Note: Golf score can be cleared at any time by pressing 'A' and 'C' simultaneously.
Reset will return to the first hole in the first round of 18 holes.
Pressing and holding 'B' at any time will advance the display to TIME mode.
On returning to GOLF COUNTER mode, the display will function as previously left.

