

DISPLAY

Top image shows all LED's turned on

NB. This watch features an easy open case back for DIY battery changing. Use a coin placed in the slot on the case back and turn in the direction indicated to either Open/Close. Please make sure the case back is closed securely.

Battery life will depend on the usage.

Battery type: CR1632

05/10

TRACKER

FRONT

SETTING THE TIME & DATE

Press button A to view the TIME.

Press button B to enter setting mode. Press A to advance the HOUR. Hold button for continuous advance until correct hour is reached. *Note: PM indicator will light at 12 noon.*

Press B to enter MINUTE mode. Press A to advance the MINUTE. Hold button for continuous advance. Press B to enter Date mode. Press A to advance the MONTH. Hold button for continuous advance. Press B to enter DAY mode. Press A to advance the DAY. Hold button for continuous advance. *Note: Date will auto-change at midnight.*

Press B to set DATE and EXIT the setting mode.

READING THE TIME

Press Button A to view the TIME.

Read the first column. The first 12 lights show the HOUR counted upwards 1-2-3-4-5-6-7-8-9-10-11-12. Example shows 06AM

Next read the middle column to count minutes (up to 4 mins maximum.) example shows 4 mins.

The right hand column shows tally markings of 5 MINUTES that have passed 05-10-15-20-25... example shows 20 mins. Add the 2 numbers together for the total minutes passed the hour. 4+20

Example shows 24 minutes passed 6th Hour.

READING THE DATE

Press Button A twice to view the DATE.

Read the first column. The first 12 lights show the MONTH counted upwards Jan-Feb-Mar-Apr-May...Dec. Example shows JUNE (6th month).

Next read the middle column to count up to 4 DAYS example shows 4 days

The right hand column shows tally markings of 5 DAYS that have passed 05-10-15-20-25-30-35... example shows 20th Day.

Add the 2 numbers together for the Date's Day.

Example shows 24th day of the June (6th month).

BACK